

## Universal Control 1.2 svn 2715 Update

Universal Control is a single file that contains the following elements:

### FireStudio Family

- Device and Launch Windows
- Driver ver 3.5.5

### StudioLive Mixer Family

- Device and Launch Windows
- Virtual StudioLive
- SL Remote iPad App
- Driver ver 3.5.5

This Universal Control update contains a driver update that resolves three known issues and contains the following improvements:

- StudioLive Family: Adds iPad support via the SL Remote application for the StudioLive 16.4.2 and StudioLive 24.4.2 (available free at Apple App Store).
- Windows 7: Resolves a known driver efficiency bug
- Mac: Resolves a Mac Pro “Westmere” processor conflict

### Installation Instructions (Mac and Windows)

1. Quit out of Universal Control and disconnect your unit from your computer.
2. Run the installer and follow the onscreen instructions. Both installers require that your computer be rebooted upon successful their completion.
3. Once your computer has restarted, connect your FireStudio or StudioLive series device and open Universal Control.
4. Open the Launch Window and go to Settings>Check Firmware to verify that your unit’s firmware is up to date
5. StudioLive users only: Once your StudioLive firmware has been updated, you will be given the option to restore your user presets and scenes back to your device’s memory, or to reset your StudioLive to factory default. If you select “reset”, your entire set of user Scenes and Presets will be deleted. This cannot be undone.

*Please Note: With any firmware update there is a small risk that some scenes or presets will be lost, because of this, it is highly recommended that you back up your scenes and presets in VSL prior to running the Universal Control svn 2108 update.*

### Known Issues (VSL 1.2 only)

- Only the link Master Sub button illuminates in VSL when Aux Return A or B is assigned to linked Subs. On the mixer and in SL Remote both Sub buttons light up as expected.

### Known Issues (SL Remote 1.0 only)

- If the iPad sleeps for 30 seconds or more, the app can disconnect from the mixer. You must force quit SL Remote and restart the app.

- Post EQ and Dynamics on the mixer (labeled Post DSP in SL Remote) is always enabled for subgroups on the mixer. In SL remote even though Post DSP toggles, it is always enabled.
- When a GEQ pair is assigned to a linked bus or the Main bus, the GEQ faders must be moved independently. Corresponding bands of the GEQ for the Left and Right channels do not move synchronously.